

How to Install Cam Bolt

Furniture Hardware Parts · furniturehardwareparts.com/installation-guides/cam-bolt

Contents

Tools Required

- drill
- depth stop
- pencil
- square
- screwdriver or hex key
- mallet when required

Hardware Required

- Cam Bolt
- matching dowels or bolts
- panel components

Key Measurements

- panel thickness
- drilling diameter
- drilling depth
- edge distance
- connector length
- tightening angle

Related Installation Guides

- [How to Install Angle Plate](#)
- [How to Install Barrel Nut](#)
- [How to Install Bed Rail Connector](#)
- [How to Install Cabinet Connector](#)
- [How to Install Conformat Screw](#)
- [How to Install Connector Bolt](#)

Related Resources

- [Related Product: Cam Bolt](#)
- [Related FAQ: Cam Bolt](#)

Need OEM installation support?

Use this guide as a planning reference, then request support for drawings, samples, and production installation checks for Cam Bolt.

[Request Installation Support](#)

Product Installation Overview

Cam Bolt installation focuses on panel thickness, hole diameter, hole depth, dowel or cam alignment, tightening direction, and flush joint quality in the Furniture Connectors and Knock Down Fittings assembly.

For B2B furniture production, use this Cam Bolt guide to standardize marking, drilling, mounting, fastening, and final inspection before the hardware is approved for cabinet, panel, or furniture assembly.

Important installation note:

This is only a simple installation tutorial. Specific adjustments should be made according to the actual furniture, panel material, and hardware specifications.

Product

Cam Bolt

Category

Furniture Connectors and Knock Down Fittings

Installation profile

Furniture Connector and Knock-Down Fitting Installation

Priority

90

Industry Data

Use these installation signals to prepare tools, verify measurements, and avoid common alignment or fastening mistakes before production use.

- **Tools to prepare:** drill, depth stop, pencil, square and screwdriver or hex key Prepare these before drilling or fastening the hardware.
- **Measurement checks:** panel thickness, drilling diameter, drilling depth and edge distance Confirm these measurements against the panel, door, drawer, or frame before installation.
- **Hardware and supplies:** Cam Bolt, matching dowels or bolts and panel components Check compatibility with the actual furniture material and order specification.
- **Step sequence:** Mark drilling positions on both panels, Drill holes to the required diameter and depth, Insert dowels, Align the panels and push them together and Tighten cam locks or connector bolts Follow the sequence so alignment errors are caught

before final tightening.

Cam Bolt

Detailed Cam Bolt Installation Tutorial

Before You Start

Before installing Cam Bolt, dry-fit Cam Bolt on the furniture part and confirm the panel thickness reference. Mark from one clean datum edge, not from a damaged corner, so repeated pieces land in the same position. Confirm panel thickness, cam or dowel hole diameter, and drilling depth before joining panels.

Installation Method

During the Cam Bolt work, use drill first, then drill or fasten gradually. Keep the hardware square to the panel, leave adjustment screws loose until alignment is checked, and compare the result with the Furniture Connector and Knock-Down Fitting Installation profile requirements. Drill with a stop, insert parts in the correct direction, and tighten only after panels are seated flush.

Final Check

After Cam Bolt is mounted, operate, pull, load, or lock the part in the same direction a user will use it. Recheck gaps, screw seating, clearance, and surface damage before approving the Cam Bolt installation for production. Inspect the joint for gaps, swelling, twist, or breakthrough before the assembly moves to packing.

Visual Step-by-Step Installation Guide

Step 1 of 6: Mark drilling positions on both panels

Furniture Connector and Knock-Down Fitting Installation diagram for Cam Bolt, synchronized with the six installation steps and showing two furniture panels, cam lock, dowel, connector bolt, drilling holes, alignment arrows, tightening rotation.

Step by Step Installation Instructions

- 1

Mark drilling positions on both panels For Cam Bolt, mark all dowel, cam, bolt, or connector centers from the correct panel face. Use drill for this operation and keep "panel thickness" as the main measurement check. Keep Cam Bolt in position without fully forcing it until the alignment is verified. Before moving to the next step, confirm opposite panel marks line up before drilling begins.

2. 2

Drill holes to the required diameter and depth For Cam Bolt, drill each connector hole with the required diameter and depth stop. Use depth stop for this operation and keep "drilling diameter" as the main measurement check. Keep matching dowels or bolts in position without fully forcing it until the alignment is verified. Before moving to the next step, confirm holes are square, clean, and not deeper than the board allows.

3. 3

Insert dowels, cam locks, bolts, or connector bodies For Cam Bolt, insert dowels, cams, bolts, or sleeves in the orientation shown by the drawing. Use pencil for this operation and keep "drilling depth" as the main measurement check. Keep panel components in position without fully forcing it until the alignment is verified. Before moving to the next step, confirm parts sit fully seated and face the correct tightening direction.

4. 4

Align the panels and push them together For Cam Bolt, bring panels together while supporting both faces so the joint does not twist. Use square for this operation and keep "edge distance" as the main measurement check. Keep Cam Bolt in position without fully forcing it until the alignment is verified. Before moving to the next step, confirm panel faces meet flush before the connector is fully tightened.

5. 5

Tighten cam locks or connector bolts For Cam Bolt, tighten gradually and alternate between connector points on long joints. Use screwdriver or hex key for this operation and keep "connector length" as the main measurement check. Keep matching dowels or bolts in position without fully forcing it until the alignment is verified. Before moving to the next step, confirm the joint closes evenly without swelling or board damage.

6. 6

Check panel flushness and joint strength For Cam Bolt, inspect the assembled joint under light pressure and from both faces. Use mallet when required for this operation and keep "tightening angle" as the main measurement check. Keep panel components in position without fully forcing it until the alignment is verified. Before moving to the next step, confirm the panel remains square, tight, and ready for packing or next assembly.

Common Installation Mistakes

- Drilling Cam Bolt connector holes without a depth stop.
- Mixing cam lock orientation between panels.
- Joining panels before dowels or bolts are fully seated.
- Over-tightening and damaging board material.

Safety and Installation Warnings

- Use drilling depth stops
- over-drilling can break through visible panel faces.
- Confirm drill depth and edge distance before assembling panel connectors.

Adjustment or Testing Notes

- Check that Cam Bolt pulls the panels tight without twisting the joint.
- Inspect panel faces for breakthrough or swelling.
- Confirm the joint remains flush after tightening.

Installation FAQ

What tools are needed to install Cam Bolt?

Typical tools include drill, depth stop, pencil, square, screwdriver or hex key. For production work, add jigs, depth stops, or templates when repeatable positioning is required.

What measurements should be checked before installing Cam Bolt?

Check panel thickness, drilling diameter, drilling depth, edge distance, connector length before drilling or fastening. Confirm dimensions against the product drawing and panel thickness.

Can Cam Bolt be installed in MDF or plywood furniture?

Most furniture hardware can be installed in MDF, plywood, particle board, or solid wood when the pilot hole, screw length, load rating, and tightening torque match the material.

What is the most common installation mistake for Cam Bolt?

Drilling Cam Bolt connector holes without a depth stop.

Can Cam Bolt be ordered for bulk furniture production?

Yes. Use the guide to define installation drawings, samples, tooling, and inspection standards before bulk furniture hardware production.