

How to Install Clavos

Furniture Hardware Parts · furniturehardwareparts.com/installation-guides/clavos

Contents

Tools Required

- tape measure
- pencil
- handle template or jig
- drill
- screwdriver

Hardware Required

- Clavos
- mounting screws
- drilling template

Key Measurements

- center-to-center spacing
- overall length
- projection
- screw length
- door/drawer thickness

Related Installation Guides

- [How to Install Aluminum Pull](#)
- [How to Install Appliance Pull](#)
- [How to Install Arch Pull](#)
- [How to Install Bail Pull](#)
- [How to Install Bar Pull](#)
- [How to Install Bin Pull](#)

Related Resources

- [Related Product: Clavos](#)
- [Related FAQ: Clavos](#)

Need OEM installation support?

Use this guide as a planning reference, then request support for drawings, samples, and production installation checks for Clavos.

[Request Installation Support](#)

Product Installation Overview

Clavos installation is driven by center-to-center spacing, drilling template control, panel thickness, screw length, and visible alignment across the Cabinet Handles, Knobs, Pulls, and Decorative Hardware front.

For B2B furniture production, use this Clavos guide to standardize marking, drilling, mounting, fastening, and final inspection before the hardware is approved for cabinet, panel, or furniture assembly.

Important installation note:

This is only a simple installation tutorial. Specific adjustments should be made according to the actual furniture, panel material, and hardware specifications.

Product

Clavos

Category

Cabinet Handles, Knobs, Pulls, and Decorative Hardware

Installation profile

Handle, Knob, and Pull Installation

Priority

92

Industry Data

Use these installation signals to prepare tools, verify measurements, and avoid common alignment or fastening mistakes before production use.

- **Tools to prepare:** tape measure, pencil, handle template or jig, drill and screwdriver Prepare these before drilling or fastening the hardware.
- **Measurement checks:** center-to-center spacing, overall length, projection and screw length Confirm these measurements against the panel, door, drawer, or frame before installation.
- **Hardware and supplies:** Clavos, mounting screws and drilling template Check compatibility with the actual furniture material and order specification.
- **Step sequence:** Decide vertical or horizontal placement, Mark center-to-center hole spacing or single knob center, Drill clean mounting holes from the front or with backing support, Insert screws from the back of the panel and Align the handle or knob

and tighten evenly Follow the sequence so alignment errors are caught before final tightening.

Clavos

Detailed Clavos Installation Tutorial

Before You Start

Before installing Clavos, dry-fit Clavos on the furniture part and confirm the center-to-center spacing reference. Mark from one clean datum edge, not from a damaged corner, so repeated pieces land in the same position. Verify center-to-center spacing, grip position, and panel thickness before drilling visible front panels.

Installation Method

During the Clavos work, use tape measure first, then drill or fasten gradually. Keep the hardware square to the panel, leave adjustment screws loose until alignment is checked, and compare the result with the Handle, Knob, and Pull Installation profile requirements. Use a template or backer block so holes stay clean and aligned through the door or drawer front.

Final Check

After Clavos is mounted, operate, pull, load, or lock the part in the same direction a user will use it. Recheck gaps, screw seating, clearance, and surface damage before approving the Clavos installation for production. Pull from normal hand angles and confirm screw length, grip clearance, and alignment across neighboring fronts.

Visual Step-by-Step Installation Guide

Step 1 of 6: Decide vertical or horizontal placement

Handle, Knob, and Pull Installation diagram for Clavos, synchronized with the six installation steps and showing cabinet door or drawer front, center-to-center marks, drill holes, handle/knob, screws, projection arrow.

Step by Step Installation Instructions

1. 1

Decide vertical or horizontal placement For Clavos, mark the visible handle or knob position with centerlines and equal edge references. Use tape measure for this operation and keep "center-to-center spacing" as the main measurement check. Keep Clavos in position without fully forcing it until the alignment is verified. Before moving to the next step, confirm hole spacing and handle height match adjacent fronts.

2. 2

Mark center-to-center hole spacing or single knob center For Clavos, drill from the finished face with backing support to protect the exit side. Use pencil for this operation and keep "overall length" as the main measurement check. Keep mounting screws in position without fully forcing it until the alignment is verified. Before moving to the next step, confirm holes are clean, straight, and on the correct center-to-center spacing.

3. 3

Drill clean mounting holes from the front or with backing support For Clavos, place the handle, knob, or pull over the holes without dragging across the finish. Use handle template or jig for this operation and keep "projection" as the main measurement check. Keep drilling template in position without fully forcing it until the alignment is verified. Before moving to the next step, confirm the base covers the drilled holes and sits flat.

4. 4

Insert screws from the back of the panel For Clavos, start screws by hand and tighten evenly from the back of the panel. Use drill for this operation and keep "screw length" as the main measurement check. Keep Clavos in position without fully forcing it until the alignment is verified. Before moving to the next step, confirm screw length grips the hardware without bottoming out or breaking through.

5. 5

Align the handle or knob and tighten evenly For Clavos, align the visible face with neighboring doors and drawers before final torque. Use screwdriver for this operation and keep "door/drawer thickness" as the main measurement check. Keep mounting screws in position without fully forcing it until the alignment is verified. Before moving to the next step, confirm the handle line is straight across the furniture front.

6. 6

Check grip clearance and visual alignment across doors or drawers For Clavos, pull from normal grip angles and check hand clearance. Use tape measure for this operation and keep "center-to-center spacing" as the main measurement check. Keep drilling template in position without fully forcing it until the alignment is verified. Before moving to the next step, confirm the hardware feels firm and does not twist under use.

Common Installation Mistakes

- Measuring Clavos hole spacing from the wrong reference edge.
- Drilling without a backing block, which can chip the panel.
- Using screws that are too short or too long for the door thickness.
- Ignoring alignment across adjacent doors or drawers.

Safety and Installation Warnings

- Confirm hole spacing before drilling replacement fronts
- wrong spacing is difficult to hide.
- Test the drilling template on scrap material before drilling finished fronts.

Adjustment or Testing Notes

- Pull Clavos from normal grip angles to verify screw engagement.
- Check vertical and horizontal alignment against neighboring fronts.
- Confirm projection and hand clearance.

Installation FAQ

What tools are needed to install Clavos?

Typical tools include tape measure, pencil, handle template or jig, drill, screwdriver. For production work, add jigs, depth stops, or templates when repeatable positioning is required.

What measurements should be checked before installing Clavos?

Check center-to-center spacing, overall length, projection, screw length, door/drawer thickness before drilling or fastening. Confirm dimensions against the product drawing and panel thickness.

Can Clavos be installed in MDF or plywood furniture?

Most furniture hardware can be installed in MDF, plywood, particle board, or solid wood when the pilot hole, screw length, load rating, and tightening torque match the material.

What is the most common installation mistake for Clavos?

Measuring Clavos hole spacing from the wrong reference edge.

Can Clavos be ordered for bulk furniture production?

Yes. Use the guide to define installation drawings, samples, tooling, and inspection standards before bulk furniture hardware production.