

How to Install Wardrobe Light

Furniture Hardware Parts · furniturehardwareparts.com/installation-guides/wardrobe-light

Contents

Tools Required

- tape measure
- drill
- screwdriver
- wire clips
- low-voltage connector tools

Hardware Required

- Wardrobe Light
- LED profile or switch
- low-voltage cable clips

Key Measurements

- profile length
- voltage
- power
- cable hole size
- driver space
- sensor detection distance

Related Installation Guides

- [How to Install aluminum LED profile](#)
- [How to Install Cabinet Light](#)
- [How to Install Cabinet Light Switch](#)
- [How to Install corner LED profile](#)
- [How to Install Desktop Power Module](#)
- [How to Install Dimmer](#)

Related Resources

- [Related Product: Wardrobe Light](#)
- [Related FAQ: Wardrobe Light](#)

Need OEM installation support?

Use this guide as a planning reference, then request support for drawings, samples, and production installation checks for Wardrobe Light.

[Request Installation Support](#)

Product Installation Overview

Wardrobe Light installation uses LED profile position, switch access, low-voltage cable routing, wire protection, and final fit checks in the Furniture Lighting and Electrical Fittings assembly.

For B2B furniture production, use this Wardrobe Light guide to standardize marking, drilling, mounting, fastening, and final inspection before the hardware is approved for cabinet, panel, or furniture assembly.

Important installation note:

This is only a simple installation tutorial. Specific adjustments should be made according to the actual furniture, panel material, and hardware specifications.

Product

Wardrobe Light

Category

Furniture Lighting and Electrical Fittings

Installation profile

Furniture Lighting and Electrical Fitting Installation

Priority

76

Industry Data

Use these installation signals to prepare tools, verify measurements, and avoid common alignment or fastening mistakes before production use.

- **Tools to prepare:** tape measure, drill, screwdriver, wire clips and low-voltage connector tools Prepare these before drilling or fastening the hardware.
- **Measurement checks:** profile length, voltage, power and cable hole size Confirm these measurements against the panel, door, drawer, or frame before installation.
- **Hardware and supplies:** Wardrobe Light, LED profile or switch and low-voltage cable clips Check compatibility with the actual furniture material and order specification.
- **Step sequence:** Plan light position, Mark profile, Drill cable pass-through holes when needed, Install the LED profile and Connect low-voltage wiring and driver Follow the sequence so alignment errors are caught before final tightening.

Wardrobe Light

Detailed Wardrobe Light Installation Tutorial

Before You Start

Before installing Wardrobe Light, dry-fit Wardrobe Light on the furniture part and confirm the profile length reference. Mark from one clean datum edge, not from a damaged corner, so repeated pieces land in the same position. Plan LED profile position, switch access, low-voltage cable route, and clearance from moving hardware.

Installation Method

During the Wardrobe Light work, use tape measure first, then drill or fasten gradually. Keep the hardware square to the panel, leave adjustment screws loose until alignment is checked, and compare the result with the Furniture Lighting and Electrical Fitting Installation profile requirements. Fit the channel straight, protect the wire, and leave access for connectors or sensors.

Final Check

After Wardrobe Light is mounted, operate, pull, load, or lock the part in the same direction a user will use it. Recheck gaps, screw seating, clearance, and surface damage before approving the Wardrobe Light installation for production. Test illumination, wire protection, profile seating, and interference with doors, shelves, or drawers.

Visual Step-by-Step Installation Guide

Step 1 of 6: Plan light position, cable route, and power supply location

Furniture Lighting and Electrical Fitting Installation diagram for Wardrobe Light, synchronized with the six installation steps and showing cabinet panel, LED profile/light, cable route, driver, switch/sensor, diffuser, power direction arrows.

Step by Step Installation Instructions

1. 1

Plan light position, cable route, and power supply location For Wardrobe Light, mark the LED profile, sensor, switch, and cable route before any channel is fixed. Use tape measure for this operation and keep "profile length" as the main measurement check. Keep Wardrobe Light in position without fully forcing it until the alignment is verified. Before moving to the next step, confirm the reference line is visible, repeatable, and matches the product title and drawing requirement.

2. 2

Mark profile, switch, or sensor positions For Wardrobe Light, prepare pilot holes or grooves while protecting low-voltage wire paths. Use drill for this operation and keep "voltage" as the main measurement check. Keep LED profile or switch in position without fully forcing it until the alignment is verified. Before moving to the next step, confirm the hole, cutout, or prepared

surface is clean and does not break through the finished face.

3. 3

Drill cable pass-through holes when needed For Wardrobe Light, place the LED profile, diffuser, sensor, or connector in the planned access direction. Use screwdriver for this operation and keep "power" as the main measurement check. Keep low-voltage cable clips in position without fully forcing it until the alignment is verified. Before moving to the next step, confirm the hardware sits flush against the panel without rocking or twisting.

4. 4

Install the LED profile, light, switch, or sensor For Wardrobe Light, secure the lighting hardware without crushing wires or blocking shelves and doors. Use wire clips for this operation and keep "cable hole size" as the main measurement check. Keep Wardrobe Light in position without fully forcing it until the alignment is verified. Before moving to the next step, confirm fasteners are seated firmly without stripping, crushing, or shifting the hardware.

5. 5

Connect low-voltage wiring and driver For Wardrobe Light, adjust cable slack, switch reach, and profile position before closing covers. Use low-voltage connector tools for this operation and keep "driver space" as the main measurement check. Keep LED profile or switch in position without fully forcing it until the alignment is verified. Before moving to the next step, confirm the gap, reveal, height, and working clearance are even from the front and side.

6. 6

Test lighting, sensor function, and heat clearance For Wardrobe Light, test light output, switching, heat clearance, and interference with moving furniture parts. Use tape measure for this operation and keep "sensor detection distance" as the main measurement check. Keep low-voltage cable clips in position without fully forcing it until the alignment is verified. Before moving to the next step, confirm movement, holding strength, and safety are acceptable before production approval.

Common Installation Mistakes

- Installing Wardrobe Light where the light profile blocks shelves or doors.
- Routing low-voltage wire without protection.
- Leaving LED profile ends unfinished.
- Testing before the profile is seated securely.

Safety and Installation Warnings

- Follow electrical safety rules and keep drivers ventilated.
- Wear eye protection and confirm all measurements before drilling.

Adjustment or Testing Notes

- Check Wardrobe Light placement, cable slack, and switch access.
- Confirm the profile or sensor does not interfere with hardware movement.
- Verify low-voltage routing remains protected.

Installation FAQ

What tools are needed to install Wardrobe Light?

Typical tools include tape measure, drill, screwdriver, wire clips, low-voltage connector tools. For production work, add jigs, depth stops, or templates when repeatable positioning is required.

What measurements should be checked before installing Wardrobe Light?

Check profile length, voltage, power, cable hole size, driver space before drilling or fastening. Confirm dimensions against the product drawing and panel thickness.

Can Wardrobe Light be installed in MDF or plywood furniture?

Most furniture hardware can be installed in MDF, plywood, particle board, or solid wood when the pilot hole, screw length, load rating, and tightening torque match the material.

What is the most common installation mistake for Wardrobe Light?

Installing Wardrobe Light where the light profile blocks shelves or doors.

Can Wardrobe Light be ordered for bulk furniture production?

Yes. Use the guide to define installation drawings, samples, tooling, and inspection standards before bulk furniture hardware production.