

Threaded Insert

Furniture Hardware Parts · furniturehardwareparts.com/metal-fasteners-for-furniture/threaded-insert

METAL FASTENERS FOR FURNITURE

Threaded Insert is a furniture fastener engineered for engineered-wood panels (MDF, particle board, plywood), giving strong pull-out resistance and fast, repeatable assembly. It is available for OEM bulk supply with samples, datasheets, and installation drawings on request.

■ Bulk Order Ready ✓ ISO 9001:2015 ☒ OEM/ODM Available [▶ Installation Guide](#)

[Request Bulk Quote](#) [View Specifications](#)

Overview

Threaded Insert is a furniture fastener engineered for engineered-wood panels (MDF, particle board, plywood), giving strong pull-out resistance and fast, repeatable assembly. The notes below cover construction, selection factors, sizes, materials, finishes, application fit, and installation for OEM production.

Industry Data

Use these product signals to compare fit, specification risk, and sourcing options before requesting samples or bulk pricing.

- **Thread / Diameter:** M8 Confirm the exact value on the order datasheet before production.
- **Length:** 25 mm Confirm the exact value on the order datasheet before production.
- **Head / Drive:** Flanged furniture head Confirm the exact value on the order datasheet before production.
- **Pilot Hole:** 3 mm Confirm the exact value on the order datasheet before production.
- **Recommended Panel:** MDF and particle board Confirm the exact value on the order datasheet before production.
- **Material options:** Stainless Steel, Carbon Steel, Zinc Alloy, Aluminum and Brass Choose material by strength, corrosion exposure, and target price.
- **Finish options:** Brushed Stainless Steel, Brushed Brass, Pewter, Flat Black and Chrome Confirm finish samples when color matching matters.
- **Application fit:** Woodworking Projects, Flat Pack Furniture, Custom Cabinets and RTA Furniture Match the product to the furniture use case, not only to the part name.

Threaded Insert

Key Specifications

Thread / Diameter	M8
Length	25 mm
Head / Drive	Flanged furniture head
Pilot Hole	3 mm
Recommended Panel	MDF and particle board
Finish / Coating	Nickel plated
Packaging	Pre-counted hardware pack

Specifications are configurable for OEM/ODM orders. Exact values are confirmed on the datasheet for your order.

How to Choose

- Screw type and thread for the board material
- Head type and drive (Pozi, Torx, hex socket)
- Length and diameter for the joint
- Board material: MDF, particle board, or plywood
- Pre-drilling and pilot-hole requirement
- Pull-out resistance and joint strength
- Bulk packaging and count per carton

Material Options

Hardened carbon steel with zinc plating is standard; stainless suits damp or outdoor-adjacent furniture. Thread geometry is tuned for chipboard and MDF holding power.

- [Stainless Steel Threaded Insert](#)
- [Carbon Steel Threaded Insert](#)
- [Zinc Alloy Threaded Insert](#)
- [Aluminum Threaded Insert](#)
- [Brass Threaded Insert](#)
- [Copper Threaded Insert](#)

Finish Options

Zinc-plated (clear or yellow) is the default for corrosion resistance; black and nickel match exposed assembly screws.

- [Brushed Stainless Steel Threaded Insert](#)
- [Brushed Brass Threaded Insert](#)
- [Pewter Threaded Insert](#)
- [Flat Black Threaded Insert](#)
- [Chrome Threaded Insert](#)
- [Satin Nickel Threaded Insert](#)
- [Matte Black Threaded Insert](#)
- [Stainless Steel Threaded Insert](#)

Application Fit

[Woodworking Projects](#)

For this application, threaded insert is specified for the typical load, environment, and usage of this application.

[Flat Pack Furniture](#)

For this application, threaded insert is specified for knock-down assembly, repeatable installation, and packaging efficiency.

[Custom Cabinets](#)

For this application, threaded insert is specified for the typical load, environment, and usage of this application.

[RTA Furniture](#)

For this application, threaded insert is specified for tool-light assembly and consistent drilling patterns.

[MDF Cabinets](#)

For this application, threaded insert is specified for the typical load, environment, and usage of this application.

[Plywood Cabinets](#)

For this application, threaded insert is specified for the typical load, environment, and usage of this application.

Recommended for These Applications

- [Threaded Insert for Woodworking Projects](#)

Installation Notes

Pre-drill the recommended pilot in MDF and particle board to prevent splitting, then drive to flush without over-torquing. Use the correct bit to avoid cam-out on high-volume lines.

Animated Installation Guide

Step-by-step SVG diagrams for installing Threaded Insert on a production line.

Open the installation guide →

Buying Notes for OEM Orders

For OEM assembly, standardize a short list of screw sizes per joint type and order in bulk cartons with consistent drive type to keep the line fast.

Comparisons

- [Confirmat Screws vs Wood Screws](#)

Related Questions

These questions are pulled into the product page as visible Q&A content, not only as plain FAQ links.

What is Confirmat Screw?

Confirmat Screw is engineered for engineered-wood panels (MDF, particle board, plywood), giving strong pull-out resistance and fast, repeatable assembly. It is specified by thread, head, drive, length, and diameter.

[Read the full Confirmat Screw FAQ →](#)

What is Euro Screw?

Euro Screw is engineered for engineered-wood panels (MDF, particle board, plywood), giving strong pull-out resistance and fast, repeatable assembly. It is specified by thread, head, drive, length, and diameter.

[Read the full Euro Screw FAQ →](#)

What is Hinge Screw?

Hinge Screw is engineered for engineered-wood panels (MDF, particle board, plywood), giving strong pull-out resistance and fast, repeatable assembly. It is specified by thread, head, drive, length, and diameter.

[Read the full Hinge Screw FAQ →](#)

What is Furniture Screw?

Furniture Screw is engineered for engineered-wood panels (MDF, particle board, plywood), giving strong pull-out resistance and fast, repeatable assembly. It is specified by thread, head, drive, length, and diameter.

[Read the full Furniture Screw FAQ →](#)

What is Threaded Insert?

Threaded Insert is engineered for engineered-wood panels (MDF, particle board, plywood), giving strong pull-out resistance and fast, repeatable assembly. It is specified by thread, head, drive, length, and diameter.

[Read the full Threaded Insert FAQ →](#)

What is Cabinet Screw?

Cabinet Screw is engineered for engineered-wood panels (MDF, particle board, plywood), giving strong pull-out resistance and fast, repeatable assembly. It is specified by thread, head, drive, length, and diameter.

[Read the full Cabinet Screw FAQ →](#)

Request Bulk Pricing

Send your specification, target market, and order volume. Our engineers reply with pricing, samples, and datasheets — usually within one business day.

Request a Quote

Tell us your project requirement. Our engineers reply within one business day with bulk pricing, datasheets, and installation drawings.